

How to Adjust the Camera

DO NOT TOUCH THE CAMERA!!

On the remote, the **BLUE** and **DARK RED** buttons control the camera.

For the Near Site Camera (YOUR camera):

1. Press the **BLUE Near** button
2. To move the camera from side to side or up and down, press the **DARK RED** navigation buttons in the direction you wish to move the camera
3. Use the **BLUE** Zoom buttons when you want to zoom in or out



DO NOT TOUCH THE CAMERA!!

On the remote, the **BLUE** and **DARK RED** buttons control the camera.

For the Far Site Camera (Remote camera):

1. Press the **BLUE Far** button
2. To move the camera from side to side or up and down, press the **DARK RED** navigation buttons in the direction you wish to move the camera
3. Use the **BLUE** Zoom buttons when you want to zoom in or out



NOTE: If your video conference is being bridged, you will not be able to adjust the far site camera